





PIECES DETACHEES
SPARE PARTS
ERSATZTEILE
ONDERDELENLIJST


PIEZAS DE RECAMBIOS
PEZZI DI RICAMBIO
スペアパーツ

ENTRETIEN
MAINTENANCE
WARTUNG
ONDERHOUD

MANTENIMIENTO
MANUTENZIONE
メンテナンス



H1	Part No. & Name	H1	Part No. & Name	H2	Part No. & Name
1	H1-01 Body Frame	13	H1-09 Bar Pin	25	H2-03 Sleeve Seat
2	H1-02 Draw Bar Lead	14	H1-10 E-6 Ring	26	H2-04 Draw Bar
3	H1-03 Sleeve Seat	15	H1-11 Balancing Bar	27	H2-05 Screw of Mouth Part
4	H1-04 Jaw Case	16	H1-12 Screw	28	H2-05-1 Nut of Mouth Part
5	H1-04-1 Jaws	17	H1-13 Handle	29	H2-21 Spanner 8.5 and 5.5
6	H1-04-2 Jaw Pusher	18	H1-14 Handle Pin		
7	H1-04-3 Press Spring	19	H1-15 Handle Lock		
8	H1-04-4 Spring Screw	20	H1-16 Handle Lock Spring		
9	H1-05 Nose Piece	21	H1-17 Lock Spring Stopper		
10	H1-06 Lever	22	H1-18 Plastic Grip		
11	H1-07 Body Pin	23	H1-19 Spanner 17 and 12		
12	H1-08 Connecting Bar	24	H1-20 Spanner 19 and 15		






UTILISATION
GEBRUIK

USE
UTILIZACION

EINSATZ
UTILIZZO

使用

CAPACITE
CAPACITY
SCHNEIDBEREICH
CAPACITEIT
CAPACIDAD
CAPACITA
キセパンテイ






ALU
ALU
ALU
ALU
ALUMINIO
ALLU
アルミニウム

→ 6.4mm
(1/4")

ACIER
STEEL
STAHL
STAAL
ACERO
ACCIAIO
スチール

→ 6.4mm
(1/4")



Choix de la longueur du rivet
Choice of rivet length
Auswahl der Blindnietenlänge
Keuze lengte klinknagels
Elección de la longitud del remache
Scelta della lunghezza del rivetto
リベットの長さで選ぶ

