


PIECES DETACHEES
SPARE PARTS
ERSATZTEILE
ONDERDELENLIJST

PIEZAS DE RECAMBIO
PEZZI DI RICAMBIO
スベリパーツ



ENTRETIEN
MAINTENANCE
WARTUNG
ONDERHOUD

MANTENIMIENTO
MANUTENZIONE
メンテナンス



Part No. & Name	Part No. & Name	Part No. & Name
H9 1 Main Handle	H9 11 Lock	H9 22 Press Spring
2 Swivel Head	12 Nut	23 Spring Screw
3 Handle	13 Connecting Head	24 Screw
4 Draw Bar Head	14 Handle Pin	25 Screw
5 Lever	15 Ring	26 Screw
6A Arbor Handle	16 Handle	27 Screw
6B Head Arbor	17 Rubber Grip	28 Screw
7 Slide Board	18 Spring screw	29 Connecting Screw
8 Wavy	19 Jaw Case	30 Connecting Board
9 Slide Sorew	20 Jaws	31 Connecting Nut
10 Connecting Bar	21 Jaw Pushbr	32 Connecting Screw

Part No. & Name
H9-2 33 Slcvcv Seat
34 Draw Bar
35 Screw of Mouth Part
36 Nut of Mouth Part
37 Spanner



1 Nettoyer ou changer
Clean or change
Reinigen oder Tauschen
Schoonmaken of te veranderen
Limpe o cambie
Pulire o cambiare
洗淨は交換